




## HOW TO ASSEMBLE MONEY MACHINE




1. Assemble two squares using 4 unwedged pipes and 4 corner fittings for each.



**Swedged Pipe**



**Unwedged Pipe**



2. Insert swedged pipes into each corner of one square. Insert the remaining unwedged pipes into the four corners of the other square.



3. Turn the two cubes onto their sides and slide them together.



4. Attach the vinyl while the unit is lying on its side. Once attached, tip unit into its upright position.

## SAFETY INSTRUCTIONS

- Do not use the blower near water or plug it in if it is wet.
- **NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!**
- Use caution when setting up / taking down. Once bolts are loosened the sections of tubing can come apart and fall down causing injury.
- Ensure players are wearing safety goggles inside the booth. Keep spectators away from the blower.
- Secure power cord to avoid a trip hazard.

## SUGGESTED GAME RULES

### Before Game Play

- Operator may or may not supply a collection pouch for the player, depending on the amount of bills they wish to give away.
- Operator may use real cash, play money, a mixture of real/play money, coupons, tickets, etc.
- Crumpled bills circulate better than crisp or flat bills. Operator may wish to keep crumpled bills inside the unit and award player with an equal amount of fresh bills as they exit.

### Game Play

1. Players must remove shoes and put on goggles before entering.
2. When operator says "GO!", player can begin collecting bills.
3. Player must remove bills from the air and not from the floor, wall or ceiling.
4. Player must stop collecting bills when operator says "STOP!"

## BEFORE RETURNING

- Disassemble unit, and wipe down vinyl if damp.
- Return parts into appropriate cases.