


SPECIAL *Event* RENTALS

HOW TO SET UP THE POPUP TENT

1 On a level surface, with a partner on either side expand the tent slightly.




2 Grab the cross frames and expand the tent completely.



3 From the middle of the tent have one person push the center upwards, allowing the other to snap in the corners.

4 To snap in the corners place one hand on top of the corner and the other on the brace. In that position lift up until you hear the corner lock. Repeat on all four corners.



5 On the mid section of every side of the tent locate the strap. Take the back clip of the strap, wrap it around, and snap it in. Repeat on all four sides.

6 Extend the tent legs by pulling the rings on the attachment at the bottom of the tent to unlock the legs. First lift all the legs into the first clip, then adjust to desired height after. Please make sure each leg is clicked to the same height. Ensure the tent is secured with weights or stakes.



HOW TO TAKE DOWN

1 Undo all the legs and lower them by pulling out the ring on the attachment at the bottom of the tent legs. Two people should lower two legs in one synchronized motion

2 After the legs are lowered undo the black straps on the sides on the tent. Then lift the canopy slightly from the edges then pull the ring and release each corner piece and ease them down.

3 Two people should stand at opposite ends and walk towards each other allowing the tent to fold into its compacted position. Place the carry bag over the tent to ensure safe transportation and storage.



[VIDEO LINK TO POPUP SET UP](#)

